


NHL SCHEDULE WATCH



LCD DISPLAY DESCRIPTION



Start times are based on selected time zone


HOW TO VIEW YOUR TEAM'S SCHEDULE




TO VIEW ALL GAMES BEING PLAYED TODAY




TO VIEW ALL NHL GAMES BEING PLAYED ON A SPECIFIC DAY




HOW TO SET YOUR WATCH





HOW TO SET ALARM, MELODY AND CHIME





TO DOWNLOAD SCHEDULE FROM PC
 • Visit Game Time's website at www.schedulewatch.com. Connect the schedule watch to a USB port on your computer using the included cable.




• After finishing download, 'UP DATE' will be displayed, and when update of new schedule is finished, the schedule will go back to normal screen

SUPPORTED OPERATING SYSTEMS

• Windows ME, Windows 2000, and Windows XP

BATTERY REPLACEMENT

• Open the battery cover
 • Put in a new lithium battery (CR2032 or equivalent) and tighten the cover



Operating Tips

1. At the start of each game the watch will play the "Star Spangled Banner" or "O Canada" for Canadian teams. If the watch plays this melody at the wrong time, check to see if your time zone is set correctly. (Time Zone can be set when after entering into set mode). If no melody is heard, check to see if the melody is set ON by observing the melody in the left upper corner.
2. The melody can be heard by pressing and holding down the button B2 for 2 seconds. Your team and time zone setting is also displayed during this time.
3. To stop the melody playing or the alarm sound, just press any button.
4. Every watch is factory pre-set to the correct time zone according to your team. If you travel to another zone, do remember to change the time zone correctly.
 E: Eastern Time C: Central Time
 M: Mountain Time P: Pacific Time
 A: Alaska Time
5. You can set the watch to give beeps per button press or be silent by setting it BEEP ON or BEEP OFF after alarm hour setting.
6. The watch will automatically resume normal time display if no button is pressed for 15 seconds.
7. If the EL backlight goes dim or the display goes blank, replace a new Lithium CR2032 battery (or equivalent). After battery replacement, remember to set your zone and team in addition to the time and date
8. Zone setting: set your zone in the time setting mode, pressing B1 or B2 to change zone (E, C, M, P, A), then press B3 to confirm and resume normal time display or B4 to confirm and continue for second setting.
9. Team setting: set your team in the time setting mode after year setting by pressing B4, pressing B1 or B2 to change team, then press B3 to confirm and resume normal time display or B4 to confirm and continue for second setting.

Please note your watch was programmed according to each team's officially released schedule prior to the start of the season. Each NHL team reserves the right to change schedules without notice. All dates and start times are subject to change. Game Time assumes no responsibility for any changes to the NHL schedule. Please check your local listings before planning any event such as going to a game.

Water/splash resistant only – do not submerge. To maintain water resistant status we recommend using common sense care, which includes avoiding any damaging blows to the watch. The opening or disassembling of the watch other than opening the battery compartment will damage the water resistance and void all warranties.

For annual schedule updates, or to order other Game Time products, please visit our website at:

www.schedulewatch.com
 Or call our toll-free Order Line at:
 888-249-9627

GAME TIME LIMITED WARRANTY

We provide a 1-year limited warranty on all Schedule Watches. This covers all components under normal wear and tear except the battery. If your Schedule Watch fails to operate we will repair or replace at our option. There is an \$8.50 handling charge that covers return postage and insurance. This limited warranty does not cover abused straps, crystals, cases, or battery replacement. For warranty issues, please contact our customer service at 888-249-9627 or via e-mail at info@gametimeshop.com.

GAME TIME LLC.

10 Stage Door Road, Fishkill, NY 12524